

III. Results

b) Demonstration – Take sample points measures

Run this

Nom	Modifié le	Type	Taille
essais	04/06/2024 14:46	Dossier de fichiers	
experiment_conditions	04/06/2024 11:18	Dossier de fichiers	
.gitignore	21/05/2024 10:04	Fichier GITIGNORE	1 Ko
compute_angles.m	10/04/2024 09:41	MATLAB Code	1 Ko
compute_stats.m	04/06/2024 11:10	MATLAB Code	5 Ko
displayPhaseAngle.m	03/06/2024 15:25	MATLAB Code	1 Ko
file_names_data.mat	03/06/2024 14:19	MATLAB Data	1 Ko
filter_Fx_Fy.m	04/06/2024 11:06	MATLAB Code	1 Ko
generate_test_file.m	04/06/2024 11:15	MATLAB Code	4 Ko
getColorForIteration.m	04/06/2024 16:49	MATLAB Code	1 Ko
loadMeanData.m	10/04/2024 09:39	MATLAB Code	1 Ko
main.m	04/06/2024 15:06	MATLAB Code	27 Ko
params_line.pssettings	31/05/2024 14:54	PicoScope 7 Data file	4 Ko
params_points.pssettings	22/05/2024 11:12	PicoScope 7 Data file	4 Ko
performLinearRegression.m	10/04/2024 09:40	MATLAB Code	1 Ko
plot_temperature.m	04/06/2024 11:32	MATLAB Code	5 Ko
plotData.m	04/06/2024 15:41	MATLAB Code	1 Ko
plotFilledAreas.m	04/06/2024 11:04	MATLAB Code	1 Ko
plotRegressionAndFilledAreas.m	17/05/2024 16:21	MATLAB Code	1 Ko
plotRegressionLines.m	10/04/2024 09:40	MATLAB Code	1 Ko
prez_measure_points.pdf	16/04/2024 10:54	Microsoft Edge PDF Document	1 019 Ko
usergetfiles.m	10/04/2024 17:17	MATLAB Code	1 Ko

MATLAB R2023b - academic use

HOME PLOTS APPS EDITOR PUBLISH VIEW

New Open Save Compare Go To Find Refactor Profiler Run Section Run and Advance Run to End Run Step Stop

FILE NAVIGATE CODE ANALYZE SECTION RUN

Current Folder: C:\Users\lucas\Desktop\PRI_Lucas\enregistrements

Editor: C:\Users\lucas\Desktop\PRI_Lucas\enregistrements\main.m

Workspace

```
1 function main()
2
3     close all
4     clc
5
6     % By default we don't plot the boxplots, we don't have samples and we
7     % don't merge the points
8     boxplots = false;
9     sample = false;
10    % merge = false;
11
12    % Decide if we want to take the sample POINTS measures
13    prompt = 'Do you want to take the sample POINTS measures (and see steps) ? (y/n): ';
14    user_response = input(prompt, 's');
15
16    if strcmpi(user_response, 'y')
17
18        currentFolder = pwd;
19        paramsFilePath = fullfile(currentFolder, 'params_points.psettings');
20        pdfFilePath = fullfile(currentFolder, 'prez_measure_points.pdf');
21        winopen(paramsFilePath);
22        winopen(pdfFilePath);
23
24    end
25
26    prompt = 'Do you want to take the sample LINE measures (and see steps) ? (y/n): ';
27    user_response = input(prompt, 's');
```

Command Window

fx >>

main.m (Function)

main()

Run

Editor - C:\Users\lucas\Desktop\PRI_Lucas\enregistrements\main.m

```
main.m x +
1 function main()
2
3     close all
4     clc
5
6     % By default we don't plot the boxplots, we don't have samples and we
7     % don't merge the points
8     boxplots = false;
9     sample = false;
10    % merge = false;
11
12    % Decide if we want to take the sample POINTS measures
13    prompt = 'Do you want to take the sample POINTS measures (and see steps) ? (y/n): ';
14    user_response = input(prompt, 's');
15
16    if strcmpi(user_response, 'y')
17
18        currentFolder = pwd;
19        paramsFilePath = fullfile(currentFolder, 'params_points.pssettings');
20        pdfFilePath = fullfile(currentFolder, 'prez_measure_points.pdf');
21        winopen(paramsFilePath);
22        winopen(pdfFilePath);
23
24    end
25
26    prompt = 'Do you want to take the sample LINE measures (and see steps) ? (y/n): ';
27    user_response = input(prompt, 's');
28
```

Command Window


```
fx Do you want to take the sample POINTS measures (and see steps) ? (y/n):
```

Answer yes "y"

Measurement circuit



Select application "Fissures surf."




Set :


- Gain H = 50 dB
- Gain V = 44 dB


Set :

- FREQ 500KHz



Set the zero while holding
the probe in the air






Click so that
it turns green

- Step : **Measure**




Try to maintain perpendicularity by pressing the **adjustable collar**, after ~2 seconds lift the probe up




- Step : **Save**

Here



- Step : **Save**


Here choose path : ['C:\Users\'',user,'\Desktop\PRI_Lucas\enregistrements\']



- Step : **Save**

Here file name : {type}_{**sample name**}_{sample index}

Example : verification_Bussy_1



Types :

- verification
- calibration

Sample name :
*“Only calibration”
 names ! :*

- perlite
- martensite
- WEL


*Don't use these
 names on
 verification !*

Sample index :

- 1
- 2
- 3
- 4
- ...


- Step : **Save**

Here select MATLAB (.mat)



- Step : **Save**

Here select « actuelle »



- Step : **Save**

Save

